




Replacing the Flex hose




1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17



18



19



Quooker®

quooker.com